


EL-WiFi-DTP+

Dual Channel External Thermistor WiFi Temperature Sensor

- Measures temperature range -40°C to +125°C (-40°F to +257°F)
- Dual channel recording through two external thermistor probes
- Wirelessly stream and view data on the EasyLog Cloud, App or on a PC
- Sensor set up is easy using free PC software
- · View and analyse multiple sensors, including graphing of historic data
- Configurable high and low alarms with indicator
- Sensor memory stores data even if WiFi is temporarily disconnected

The EL-WiFi-DTP+ datalogging sensor measures the temperature of the environment in which the two probes are situated. This high accuracy sensor is typically accurate to ±0.2°C/±0.4°F (-15° to +80°C/+5° to +176°F). The unit is freestanding, but can be attached to a wall or surface using the bracket provided. The unit can be clipped in and out of the bracket as required. The probes are connected to the sensor via a 160mm Y splitter cable which is provided.



The EL-WiFi-DTP+ has a protection rating of IP43 and the probes IP67. The sensor is IEEE 802.11b compliant, supports WEP, WPA/ WPA2 encryption and enterprise networks.



	Minimum	Typical	Maximum	Unit
Battery life		>6		Months
USB supply voltage	4.5	5	5.5	Vdc
Operating temperature range	-20 (-4)		+60 (+140)	°C (°F)
Logging period (user configurable)	10 sec	10 min	12 hrs	
Transmission period (user configurable)	1 min	1 hr	24 hrs	
Temperature measurement range	-40 (-40)		+125 (+257)	°C (°F)
Temperature measurement resolution		0.01 (0.02)		°C (°F)
Temperature display resolution		0.01		°C
Temperature accuracy		±0.2°C/±0.4°F (-15 to +80°C/ +5 to +176°F)	±0.6°C/±1.2°F (-40 to +125°C/ -40 to +257°F)	°C/°F
Dimensions	82 x 70 x 36mm (3.22 x 2.75 x 1.41")			



PSU-5VDC-USB-USA	USB Mains Power Adapter for USA
PSU USB-UK	USB Mains Power Adapter for UK
PSU USB-EU	USB Mains Power Adapter for EU
EL-WiFi-Alert	Audible and Visual Alarm for EL-WiFi Data Logging Sensors
EL-PROBEA-3.0M-TP-GLY	External Thermistor Glycol Probe



EL-WIFI WALL BRACKET Wall mounting

bracket for EL-WiFi

EasyLog

W = A MAX

sensors

2x EL-PROBEA-3.0M-TP+ 3m Thermistor

Probes

CABLE USB A-MICRO B USB Type A to Micro B













EL-WiFi-DTP+

Dual Channel External Thermistor WiFi Temperature Sensor



EL-WiFi-WIN

Lascar's WiFi software is available as a free download from: www.lascarelectronics.com/software/easylog-wifi. Easy to install and use, EL-WiFi-WIN allows easy connection of sensors to a WiFi network. The user can select where data is stored - the PC or the Cloud.



EasyLog Cloud

Interact with sensors via any internet-enabled device. Manage and monitor sensors, access event logs and set up email alerts. A Cloud account is created during the WiFi sensor set-up process using EL-WIFI-WIN with the choice of two account types depending on which features are required.

EasyLog Cloud App

For users on-the-go, download the EasyLog Cloud app on the App Store and GooglePlay. This app extends Cloud access and visibility to smartphone and tablet users, delivering an enhanced user experience and features otherwise unavailable via the traditional mobile web interface.









Download the latest version of the software free of charge from www.lascarelectronics.com/software/easylog-wifi

Battery Life and Power Supply

The battery can be recharged (unit must be between 0 - 40°C) via a PC, a USB +5V wall adapter, or a portable USB battery pack using the USB lead provided. It can also be permanently powered by a USB wall adapter or USB battery pack. Readings may be affected while the internal battery is being charged. However, once charged, continued connection of the charger will have no effect.

Battery life is dependent on: transmission period, WiFi encryption method, WiFi encryption key rotation frequency (determined by the router/access point), signal strength between router/access point and WiFi device, presence volume and type of WiFi traffic from other devices, sample rate and operating temperature.

Specifications liable to change without prior warning





CMI BELGIUM

Avenue de Ramelot 3 B - 1480 Saintes (Sint Renelde) Tel : +32 (0)2 531 11 21 info@cmitest.com

CMI THE NETHERLANDS

Luchthavenweg 81 NL – 5657 EA Eindhoven Tel: +31 (0)402 88 87 57 infonl@cmitest.com

CMI FRANCE

Ecoparc d'Affaires F- 41210 Neung-sur-Beuvron Tel: +33 (0)2 54 95 70 95 infofr@cmitest.com Agence Rhône Alpes : F- 26160 La Bégude-de-Mazenc Tel : +33 (0)4 75 54 57 26

